

Digital smoker (Schoku plug)

Key	Qty	Description	Part #	Kriswell Art.No.:
1	1	DOOR ASSEMBLY	FDES301101C	180 700
2	1	LED LIGHT KIT	FDES30304	180 701
3	1	DOOR HINGE BRACKET KIT	FDES30100	180 702
4	1	MEAT PROBE HOUSING	FDES30103C	180 703
5	1	DOOR LATCH ASSEMBLY	FDES301110	180 704
6	1	SMOKER BODY ASSEMBLY	FDES30306ACE	180 705
7	1	LEFT LEG	FDES30113C	180 706
8	1	GREASE TRAY ASSEMBLY	FDES301090	180 707
9	1	WATER PAN	FDES301085	180 708
10	1	SMOKER BOX	FDES301093	180 709
11	1	DRIP PAN ASSEMBLY	FDES301086	180 710
12	2	WHEEL KIT	FDES30117	180 711
13	4	COOKING GRATE	FDES301084C	180 712
14	1	CONTROL PANEL DISPLAY KIT	FDES30110LCE	180 713
15	1	HEATING ELEMENT REFLECTOR SUPPORT	FDES30106	180 714
16	1	HEATING ELEMENT	FDES30111C	180 715
17	1	MEAT PROBE	FDES301074	180 716
18	1	THERMOSTAT KIT	FDES30108C	180 717
19	1	THERMOSTAT KIT	FDES30107C	180 718
20	1	FRONT FASCIA, LOWER	FDES30325	180 719
21	1	RIGHT LEG, FRONT	FDES30114C	180 720
22	1	RIGHT LEG, REAR	FDES30115C	180 721
23	1	CONTROL PANEL FASCIA KIT	FDES30301	180 722
24	1	HEATING ELEMENT REFLECTOR	FDES30105	180 723
25	1	POWER BOARD KIT	FDES30303C	180 724
26	1	POWER BOARD HOUSING	FDES30104	180 725
27	1	POWER SUPPLY CORD KIT	FDES30109CE	180 726
28	1	CONTROL PANEL HOUSING	FDES30102	180 727
29	1	OUTSIDE MEAT PROBE HOLDER	FDES301163A	180 728
30	1	CORD WRAP	FDES301164A	180 729
...	1	PRODUCT GUIDE, EUROPE	42805290	180 730
...	1	ELECTRICAL REPLACEMENT MANUAL (ONLINE ONLY)	42805354	
...	1	CONTROL PANEL STICKER	FDES301116	170 731

WARRANTY PARTS DIAGRAM

